



















**Optional Connectors (not supplied)**







<p>Motorola® (square) (SCA024)</p> 	<p><b>Motorola® phones with the Square connector</b>  A630, A830, A835, A920, A925, A1000, C331 and C332 (TDMA versions), C333 (CDMA with antenna), C341, C343, C353 (TDMA), C975, E310, E550, E1000, MPx220, ROKR, T280i, T300p, T720, T720i, T721, T721i, T722i, T730, T731, V70, V260, V262, V265, V300, V400, V500, V505, V525, V545, V547, V550, V551, V600, V620, V635, V710, V810, V975, V1050, V60, V60i, V60c, V60p(PTT), V60s, V60t, V60t Colour, V60g, V60x, V66, V66i, V120c, 120t, 120x, 120c, 120e, 270c, 280, phones and V200 Personal Communicator.</p>
<p>Siemens - BenQ (SCA003)</p> 	<p><b>Siemens - BenQ®</b>  E71, E81, EF81, EL71, S68, SL91</p>
<p>Nintendo® GBA (SCA004)</p> 	<p><b>Dedicated Nintendo Gameboy® advanced Connector</b>  Nintendo Gameboy handheld games system and older DS game systems</p>
<p>Nintendo® GBM (SCA005)</p> 	<p><b>Dedicated Nintendo Gameboy Micro® Connector</b>  Nintendo Gameboy Micro handheld games system</p>
<p>Samsung® 2.5mm (SCA007)</p> 	<p><b>Samsung® devices</b> --- SPH-A920, SPH-A940, SPH-A820, SPH-A560, SPH-A880, SPH-A800, SPH-A740, SPH-A760, MM-A700, VM-A680, SPH-A660, SPH-A600, VGA1000, SPH-N400, SPH-A500, SPH-N240, SPH-A460</p> <p><b>Kyocera® devices</b> --- Phantom Series, KE413, KE413C, KX413, KE414, KE414C, KX414, Rave/K10 Royale Phone Series, K9, K10, K433, K434, KE433, KE433C, KE434, KX433, KX434, Blade Phone Series, KE424C, KX424</p> <p><b>Palm® Devices</b> --- Tungsten E, Zire 72</p>
<p>Panasonic® (SAC008)</p> 	<p><b>Panasonic®</b>  GD92, GD52, GD93, GD75, GD95, TX310, TX320</p>

<p>Palm One® (SAC009)</p> 	<p><b>Palm one connector</b> 600, 650, 680 and T5 PDA's</p>
<p>Alcatel® (SAC010)</p> 	<p><b>Alcatel®</b> OT511, OT310, OT535, OT300, OT301, OT302, OT500, OT221, OT700</p>
<p>Siemens® C55 (SAC011)</p> 	<p><b>Siemens® C55 series phones</b> A51, A52, A53, A55, A57, A60, A62, A65, A70, A75, AL21, AL72, AL75, AL76, AX21, AX72, AX75, AX76, C55, C60, C62, C65, C70, C72, C75, CC55, CC60, CC62, CC65, CC70, CC72, CC75, CF62, CF75, CF110, CFX65, CL75, CX65, CX70, CX75, M55, M60, M65, M75, MC55, MC60, MC65, MC75, ME75, S55, S65, S75, SP55, SP65, SP75, SF65, SK65, SL55, SL65, SL75, SG75, SXG75, SX1.</p>
<p>Siemens® C25 (SAC012)</p> 	<p><b>Siemens® C25 series phones</b> A35, A36, A40, A50, C25, C28, C35, C35i, C45, M35, M35i, M45, M50, ME45, MT50, S25, S35, S35i, S45, S45i, SL42, SL45, SL45i</p>
<p>Sanyo® (SAC013)</p> 	<p><b>Sanyo®</b> PM-8200, RL-4920, RL-4930, SCP-200, SCP-2400, SCP-3100, SCP-4900, SCP-5300, SCP-5400, SCP-5500, SCP-7200, SCP7300, SCP-8100, SCP-8200, VI-2300, MM-5600, MM-7400, MM-7500, MM-8300, MM-9000, EL-4920, RL-4930, SCP-200, SCP-2300, SCP-2400, SCP-3000, SCP-3100, SCP-350, SCP-4000, SCP-4500, SCP-4700, SCP-4900, SCP-5000, SCP-5150, SCP-5300, SCP-5400/RL2500, SCP-5500/VM4500, SCP-6000, SCP-6200, SCP-6400, SCP7200/RL2000, SCP7300/RL7300, SCP-8100, SCP-8200/PM-8200, VI-2300/4600/8100/5300/7200/5000/5150/6000/6200/C304/RL2000/2500/5400/5500/7300</p>
<p>Motorola® 3mm jack (SAC014)</p> 	<p><b>Motorola®</b> C113, C113a, C115, C139, C155, C200, C300, C331 (GSM version), C332 (GSM version), C333 (GSM version), C350 (without antenna), C336, C450, C550, T190, T191, T193, T193m, V150, T2260, T2282, T2290, T2297, V.Series™ V2260, V2267, V2282, V2290, V2297, V2397, V220, V220 PINK</p>



Freeloader

<p>Sagem® 918 (SAC015)</p> 	<p><b>Sagem®</b> MY-X2, MY-X3, MY-X5, MY-X6, 3000 series (apart from 3078, 3088, WA3050), 900 series</p>
<p>Micro USB (SAC016)</p> 	<p><b>Micro USB 8pin</b> Compatible with Mobile devices that use the new Micro USB connection</p>
<p>Sony Ericsson® (Small) (SCA023)</p> 	<p><b>Sony Ericsson® Small connector</b> A2218z, A2618, A2618s, A2628, A3618s, F500i, J210i, J300i, K300i, K500i, K508i, K600i, K608i, K700i, P800, P900, P910i, R300d, R300LX, R300z, R320, R320s, R380 WORLD, R380e, R380s, R520m, R600, S700i, T20e, T20s, T28 WORLD, T28z, T29, T29s, T39m, T60c, T60d, T61c, T61d, T61LX, T61z, T62u, T65, T66, T68, T68i, T100, T105, T200, T226, T230, T290i, T300, T306, T310, T316, T600, T610, T616, T620, T630, V600i, V800, Z200, Z300i, Z600, Z800i, Z1010</p>
<p>New Nokia / Motorola (SCA022)</p> 	<p><b>Nokia® / Motorola® Thin connector</b> New "Classic" Phone range from Nokia (6500)  Motorola® Moto Q9, Moto U9, Moto V8</p>
<p>New Samsung (SCA025)</p> 	<p><b>Samsung® Wide Thin connector</b> G600, I450, L600, L760</p>
<p>Spaire Hub (SCA001)</p> 	<p><b>Replacement / Spare Hub for freeloader</b> Replacement / Spare hub for the freeloader enabling you to have one on charge while charging another</p>

Freeloader

<p>Spare Hub (SCA020)</p> 	<p><b>Replacement / Spare Hub for freeloader (Pink)</b></p> <p>Replacement / Spare hub for the freeloader enabling you to have one on charge while charging another</p>
<p>AA / AAA batter charger (SC8090)</p> 	<p><b>AA/AAA battery charger for the freeloader</b></p> <p>Charge up 2 x AA (supplied) or 2 x AAA from the freeloader, Includes emergency charging cable for the freeloader and flashlight.</p>
<p>Super charger (SC8091)</p> 	<p><b>Super charger for the freeloader (Green)</b></p> <p>Supercharger is a super tough, all weather solar cell, capable of charging Freeloader in half the time. Simply strap Supercharger to a backpack, bike pannier or travel bag and plug it into Freeloader's hub for instant power wherever your travels take you.</p>
<p>Super charger (SC8092)</p> 	<p><b>Super charger for the freeloader (Pink)</b></p> <p>Supercharger is a super tough, all weather solar cell, capable of charging Freeloader in half the time. Simply strap Supercharger to a backpack, bike pannier or travel bag and plug it into Freeloader's hub for instant power wherever your travels take you.</p>
<p>Case for freeloader (SCA019)</p> 	<p><b>Carry case for the freeloader (Green)</b></p> <p>Protect Freeloader in this custom made, hard wearing travel pouch. The carry pouch is big enough to hold a Freeloader, charging cable and up to 6 power adaptors. The carry pouch has a belt loop for easy portability</p>
<p>Case for freeloader (SCA021)</p> 	<p><b>Carry case for the freeloader (Pink)</b></p> <p>Protect Freeloader in this custom made, hard wearing travel pouch. The carry pouch is big enough to hold a Freeloader, charging cable and up to 6 power adaptors. The carry pouch has a belt loop for easy portability</p>

Freeloader

<b>12V car charger (SCA017)</b>	<b><i>12V car charger for the freeloader</i></b>
	The Freeloader USB Car Charger, great for charging and powering the freeloader or any portable device that is usually charged via a computers' USB port.
<b>Mains Charger (SCA018)</b>	<b><i>Mains charger for the freeloader</i></b>
	The Freeloaders USB Mains Charger, great for charging and powering the freeloader or portable device that is usually charged via a computers' USB port.

V6 (march 2008)